DRESSER-RAND.

CO₂ Compression for Fossil Fuel-fired Power Plants

Mark J. Kuzdzal Director Business Development 13-May 2015



DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED

Safe Harbor Disclosure

The Private Securities Litigation Reform Act of 1995 provides a "safe harbor" for certain forward-looking statements so long as such information is identified as forward-looking and is accompanied by meaningful cautionary statements identifying important factors that could cause actual results to differ materially from those projected in the information.


The use of words such as "may", "might", "will", "should", "expect", "plan", "outlook", "anticipate", "believe", "estimate", "appear", "project", "intend", "future", "potential" or "continue", and other similar expressions are intended to identify forward-looking statements.

All of these forward-looking statements are based on estimates and assumptions by our management that, although we believe to be reasonable, are inherently uncertain. Forward-looking statements involve risks and uncertainties, including, but not limited to, economic, competitive, governmental and technological factors outside of our control, that may cause our business, industry, strategy or actual results to differ materially from the forward-looking statements.

These risks and uncertainties may include those discussed in the Company's most recent filings with the Securities and Exchange Commission, and other factors which may not be known to us. Any forward-looking statement speaks only as of its date. We undertake no obligation to publicly update or revise any forward-looking statement, whether as a result of new information, future events or otherwise, except as required by law.

Outline

- Brief Overview of the Power Penalty
- Review of Compression Technology Research
 - Multi-stage centrifugal
 - Intercooled centrifugal (liquid cooled diaphragm)
 - Shockwave high ratio compression
- Conclusions



DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



Bringing energy and the environment into harmony."

CO₂ Compression

- Compression is an integral part of any CO₂ capture system.
- Separation systems deliver CO₂ near 1 Bara and compression is required to increase pressure and reduce volume, making transport more practical.
 - □ Pipelines typically require ~ 2215 PSIA (153 Bara).
 - □ Injection pressures vary. (50 Bar 600 Bar)
 - Given the high flow volumes, centrifugal compressors are generally employed instead of positive displacement screw or reciprocating compressors.
 - Small pilots (1-30 MW) would utilize positive displacement compressors
- Coal-based electric generating plants that are fitted with CO₂ capture systems have a compression penalty.
 - This penalty can range from 8–12% depending on the CO₂ exhaust state (temperature, pressure and purity) of the carbon dioxide prior to compression.
- With 90% capture typical compression flow rates are:
 - □ 1,000,000 lbm/hr (454,000 Kg/hr) of CO₂ for a 550 MW PC unit
 - □ 700,000 lbm/hr of (318,000 Kg/hr) of CO₂ for a 400 MW PC unit

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED

4



CO₂ Compression Experience


- Dresser-Rand has more than 400 units in carbon dioxide service, totaling more than 900,000 HP (671 MW)
 - □ ~ 100 centrifugal compressors
 - □ ~ 300 reciprocating compressors
 - □ ~ 250 units are in CO2 injection service
- Centrifugal
 - First shipped in 1948
 - Max discharge pressure;
 - More than 8000 psia (552 bara) delivery 2011
 - Max inlet flow greater than 48,000 acfm (82,000 m3/hr)
 - □ Total installed power > 400,000 HP (>300MW)



5

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED








Multi-stage Centrifugal Compression

- DATUM[®] product is available in 15 different sizes
 - Mole Weights from 2-100
 - □ Discharge pressures ranging up to 15,000 psig (1,000 bar)



- □ Flow rates from 5,400 cfm (9,200 m3/h) to 700,000 cfm (1,200,000 m3/h)
- □ Shaft power ratings to more than 120,000 HP (90 MW)
- It is believed that D-R currently holds the record for the highest gas density compressor ever produced with a discharge pressure of 550 bar (8,000 psi) with CO₂.
- Research continues to focus of developing new aerodynamic stages capable of higher efficiency over a broad operating flow map and higher head, enabling smaller, higher speed equipment.
 - CO₂ has a relatively low speed of sound and traditionally this class of equipment has been designed to operate sub-sonically, limiting impeller inlet relative Mach number to less than 1.

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



Example: North Sea CO₂ Injection Compressor

- First CO₂ re-injection project for the purpose of mitigating greenhouse emissions
- As of Jan 2015, 15.2 million tonnes CO₂ injected in 20 years.
- Objective: reduce the CO₂ content in methane from 9% to 2.5% (sale specification)
- Capture the CO₂ from an amine plant
- CO₂ storage in an aquifer
- Start-up: Aug 1996
- Injection: ~ 0.75 mill tonne CO_2/yr
- Availability: 98-99%




8

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



- DOE, SwRI and Dresser–Rand: Successfully completed DOE grant award DE-FC26-05NT42650
- Internal heat exchangers were developed and placed inside a multi-stage compressor casing
 - Integrated into the aerodynamic flow path
- The red flow path is the CO₂ gas path and blue region represents a cooling medium
- This approach eliminates the need for the CO₂ to exit the casing, travel through piping to a external cooler, then re-enter through another nozzle leading to the next stage.
- The internal heat exchanger results in no pressure drop and fits within the same envelope of the standard internal diaphragm (Moore, et al., 2007).





Photograph of Generation-1 Cooled Diaphragm Test Rig

Reference; J. Moore, M. Nored and K. Brun, "Researchers Seek to Economically Compress Large Volumes of Carbon Dioxide," Pipeline and Gas Journal, 2007.

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



Bringing energy and the environment into harmony.*

- Test results show cooled diaphragm can remove up to 55% of the heat of compression in each stage
- The technology led to the development of a pilot scale demonstration in a 3 MW, 6-stage back-to-back, 25:1 pressure ratio compressor in a CO₂ test loop constructed and operated at SwRI.

Dresser-Rand 6-stage CO₂ Compressor with Generation-2 Cooled Diaphragms






10

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



- The D-R compressor installed at SwRI is a D12R6B, 37 inch (0.93 M) case bore, 20 inch (0.5 M) diameter impellers
- Diaphragms were successfully developed with the same pressure recovery as a standard compressor flow path.
- The compressor was operated first without cooling and compared to identical operating conditions with cooling allowing for an apples-to-apples comparison.
- Cooled diaphragm technology reduces compressor power consumption by 3.0% (near surge) to
 8.0% (near choke) when compared to adiabatic case with intercooling between the two sections.





DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



- Generation 3 concepts envisaged.
 - Potential for up to 12+% savings with respect to the baseline conventional compressor
- Generation 3 endeavors to develop an advance heat exchanger design, which has the potential of reaching:
 - Similar power as an integrally geared compressor
 - More compact package
 - Improved reliability, to 99% availability

12

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



Ramgen – SuperCompressor[™] – DATUM[®] S – History

- A by-product of a shock wave is compression and heat
 - Technology has been applied in supersonic jet engine inlet designs for decades
- In 2008, D-R invested in Ramgen's supersonic technology.
 - DOE Project DE-FE-0000493 "Ramgen Supersonic Shock Wave Compression and Engine Technology"
- Late 2012 in Olean, NY, the team successfully tested a supersonic CO₂ compressor achieving a 9:1 pressure ratio in a single rotating disk.
 - Proof of concept successful
- On Aug 8th, 2014, D-R announces the opening of the Seattle Technology Center along with the 11,000 Sq Ft testing lab.
 - Initial staffing is comprised of 19 engineers and support staff, all of whom are former Ramgen Power Systems employees.



Copyright 2015



CO₂ Supersonic Compressor

- 10:1 pressure ratio with single rotating disk on CO_2
 - Enables a 100:1 pressure ratio in a low-pressure (LP) and high-pressure (HP) case configuration

o 22 PSIA (1.52Bara)=>2215 PSIA (153 Bara)

- Compression equipment
 - ~ 70% weight and size of traditional in-line centrifugal offering
 - ~ 50% weight and size of an integrally geared centrifugal offering
 - 30% aerodynamics turndown
- Integration of waste heat for amine regeneration or boiler feed water preheat

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED

DRESSER RAND.

Bringing energy and the environment into harmony."

SuperCompressor[™] – DATUM[®] S – Shock Wave Compression

- Build 2, the path to a commercial product
 - Embodies patent-pending technology
 - □ Rig size 13,400 HP (10 MW) shaft power level
 - Mass flow 86 lbm/sec (40 Kg/Sec) (66 MMSCFD)
 - ~ 200 MW coal-fired plant
 - 220 psig suction, 2200 psig discharge pressure HP stage
 - Program plan includes:
 - Design, fabrication, assembly and test
 - Test phase started March 2015
 - Pressure ratio of 9.7:1.0 achieved
 - Test phase expected conclusion August 2015
 - Follow-on compressor pilot demonstration program at a client site targeted for 2016

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



CO₂ Test Facility


- CO_2 and Inert Test Gas
 - 220 PSIG Inlet
 - 2200 PSIG Discharge
 - 3363 PSIG Discharge Design Rating
 - 1500 # ANSI, 5000 PSIG Helium and 1000 PSIG Nitrogen utility gas
- 10 MW VFD Driven Motor
- CO₂ Gas collection system
- Cooling Tower





Bringing energy and the environment into harmony."





DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED




Bringing energy and the environment into harmony."

Benefits with Respect to Integrally Geared

- Smaller footprint, less equipment, less piping, less intercoolers
- Higher compression ratios:
 - **10:1** ratio in single rotating disk
- Discharge temperatures exceeding 550 F (290 C)
 - Benefits clients that can utilize waste heat for steam production or amine regeneration, etc.
- Waste heat recovery enables unmatched overall system efficiency.

18





Comparison for 100:1 Pressure Ratio

Supersonic

- LP and HP smaller frame size
- One rotating disk / case
- Potential for mid-grade waste heat (550F)
- 1 intercooler

Traditional Centrifugal

- LP and HP smaller
 frame Size
- Multiple impellers
- Low grade waste heat (240F)
 - 3 intercoolers

_

IG Frame

- Much larger frame size
- Multiple impellers
- Low grade waste heat (140F)
- Up to 6 intercoolers

19

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



Summary DATUM® S

- In 2008, Dresser-Rand invested in Ramgen to support on-going CO₂ compressor technology development
 - Consistent with strategy to maintain leadership in CO_2 compression:
 - Team has leveraged the successes and lessons learned from our build 1 compressor development efforts and test results
 - CFD, validated via test, used to verify SuperCompressor[™] performance
 - Client technology advisory council and VOC sessions underway.
- In 2015, Dresser-Rand expects to:
 - Conclude rig testing, enter scale up R&D program to further improved efficiency
 - Identify and engage technology collaboration partner

20

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



Summary

- The integrally geared (IG) compressor is the current benchmark for overall shaft power, but is very large and incorporates many coolers, bearings and seals:
 - Reduced reliability
- Inline centrifugal is more robust, more reliable but generally will consume slightly more power:
 - Will have a reduced footprint over IG
- Internally-cooled inline centrifugal test results show up to a 8% power savings over the same non-cooled inline centrifugal, but with slight increase of compressor costs due to manufacture of liquid-cooled diaphragms.
- DATUM[®] S Supersonic compression solution:
 - High ratio results in slight increase of shaft horsepower over traditional centrifugal compressors
 - Delivers usable heat which when integrated in to system, will produce the lowest overall power for the compression service
 - Single rotating disk results in smaller footprint, reduced CapEx.
 - Size reduction of 33% percent compared to inline centrifugal.

DRESSER-RAND PROPRIETARY - REDISTRIBUTION PROHIBITED



Bringing energy and the environment into harmony."





mkuzdzal@dresser-rand.com

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED



www.dresser-rand.com info@dresser-rand.com

DRESSER-RAND PROPRIETARY – REDISTRIBUTION PROHIBITED